



HAGS® Platform Hopper

MASW5932310M











Platform Hopper

MASW593231OM


Rev: 14

20/06/24



























▲ WARNING

Playground equipment installed over hard surfaces such as concrete, asphalt or packed earth may result in serious injury or death from falls. Make sure that appropriate safety surfacing is present, before allowing children to play.

MARNING

eauipment.

equipment.

slides.

✓ Watch your head! Do not run

under bridges, decks, stairs, or other

Children have strangled and died while their clothes caught on slides and other playgrour equipment. Before allowing children to play remove helmets, scarves, necklaces, hood cords, neck drawstrings, and mittens connected through the sleeves. Also, remove any foreign ropes, strings, or shoe laces that may be tied to equipment

WARNING


All playground equipment and rubber surfaci may become hot enough to cause burns. Check for hot surfaces before allowing childre to play. Children should wear appropriate shoes at all times

▲ WARNING


Playing tag or running on or under playgroun equipment can lead to serious injuries from falls, collisions, and head strikes. do not rur on or under playground equipment. Pay attention while playing and be careful.

Platform Hopper

MASW5932310M









▲ WARNING

Playground equipment installed over hard surfaces such as concrete, asphalt or packed earth may result in serious injury or death from falls. Make sure that appropriate safety surfacir is present, before allowing children to play.

WARNING

Children have strangled and died while their clothes caught on slides and other playgroun equipment. Before allowing children to play remove helmets, scarves, necklaces, hood cords, neck drawstrings, and mittens connected through the sleeves. Also, remove any foreign ropes, strings, or shoe laces that may be tied to equipment

WARNING

All playground equipment and rubber surfaci may become hot enough to cause burns. Check for hot surfaces before allowing childre to play. Children should wear appropriate shoes at all times

▲ WARNING

Playing tag or running on or under playgroun equipment can lead to serious injuries from falls, collisions, and head strikes. do not rur on or under playground equipment. Pay attention while playing and be careful.

"play smart" rules

5-12

✓ Do not play on broken or damaged equipment. Report it. ✓ Do not play without adequate safety

surfacing below and around equipment. ✓ No helmets, necklaces or drawstring should be worn while on equipment. ✓ Be careful of hot paly surfaces and always wear shoes while playing. ✓ Do not play tag or run on playgrou

equipment and do not jump off of eauipment. ✓ Watch your head! Do not run under bridges, decks, stairs, or other

equipment.

✓ Be careful when equipment is wet. Do not play on snowy or icy equipmen ✓ Do not climb on roofs, railings, or posts, or on top of crawl through tube slides.

✓ Slide sitting down, feet first, and on at a time. Do not slide up chutes or

✓ Adults – do not slide with a child on your lap. It can injure your child's legs ✓ Before letting go of overhead bars, hang down still, bend your knees a little and drop straight down with both feet. ✓ Swing sitting down and do not jump out while swinging. Do not twist chain

