

HAGS[®] Rocking Equipment

MASW36720










	NR.	Description MA	Item Number	Qty
	1	MK6S M10x20 mm	8008451	8
[2	Ø11x24x2 mm	8008850	8




























١.	"play smart" rules		
1.	✓ Do not play on broken or damaged		
	equipment. Report it. ✓ Do not play without adequate safety surfacing below and around equipment.		
g			
	✓ No helmets, necklaces or drawstrings		
	should be worn while on equipment.		
	 Be careful of hot paly surfaces and 		
	always wear shoes while playing.		
d 🗸 🗸 Do not play tag or run on playgr			
	equipment and do not jump off of equipment.		
	✓ Watch your head! Do not run		
	under bridges, decks, stairs, or other		
е	equipment.		
t 👘	Be careful when equipment is wet.		
	Do not play on snowy or icy equipment.		
	✓ Do not climb on roofs, railings, or		
	posts, or on top of crawl through tube		
q	slides.		
Ť	✓ Slide sitting down, feet first, and one		
n	at a time. Do not slide up chutes or		
	tubes.		
	✓ Adults - do not slide with a child on		
	your lap. It can injure your child's legs.		
	✓ Before letting go of overhead bars.		
d	hang down still, bend your knees a little		
	and drop straight down with both feet.		
	✓ Swing sitting down and do not jump		
	out while swinging. Do not twist chains.		



Rev: 14 26/07/24 U













	"play smart" rules	
Playground equipment installed over hard surfaces such as concrete, asphalt or packed earth may result in serious injury or death from falls. Make sure that appropriate safety surfacing is present, before allowing children to play.	 ✓ Do not play on broken or damaged equipment. Report it. ✓ Do not play without adequate safety surfacing below and around equipment. ✓ No helmets, necklaces or drawstring; 	
Children have strangled and died while their clothes caught on slides and other playground equipment. Before allowing children to play, remove helmets, scarves, necklaces, hood cords, neck drawstrings, and mittens connected through the sleeves. Also, remove any foreign ropes, strings, or shoe laces that may be tied to equipment	should be worn while on equipment.	
All playground equipment and rubber surfacing may become hot enough to cause burns. Check for hot surfaces before allowing children to play. Children should wear appropriate shores at all times.	✓ Do not climb on roofs, railings, or posts, or on top of crawl through tub slides. ✓ Slide sitting down, feet first, and of at a time. Do not slide up chutes or tubes. ✓ Adults – do not slide with a child	
Playing tag or running on or under playground equipment can lead to serious injuries from fails, collisions, and head strikes. do not run on or under playground equipment. Pay attention while playing and be careful.	your lap. It can injure your child's legs ✓ Before letting go of overhead bars, hang down still, bend your knees a little and drop straight down with both feet. ✓ Swing sitting down and do not jump out while swinging. Do not twist chains	

© Playpower inc hags@hags.com www.hags.com $\boldsymbol{HAGS}^{\text{\tiny o}}$

Rev: 14 26/07/24













Rev: 14 26/07/24













	WARNING
surfaces sud earth may res falls. Make su	equipment installed over hard h as concrete, asphalt or packed sult in serious injury or death from re that appropriate safety surfacing before allowing children to play.
	WARNING
Children have strangled and died while the clothes caught on silices and other playgrou- equipment. Before allowing children to play remove heimets, scarves, neckdaces, hooo cords, neck drawstrings, and mittens connected through the sileeves. Also, removi any foreign ropes, strings, or shoe laces thir may be leid to equipment.	
	WARNING
may becom Check for hot to play. Chi	equipment and rubber surfacing to hot enough to cause burns. surfaces before allowing children ldren should wear appropriate shoes at all times.
	WARNING
equipment c falls, collision on or unde	running on or under playground an lead to serious injuries from us, and head strikes. do not run r playground equipment. Pay while playing and be careful.

Do not play on snowy or icy equipment $\checkmark\,$ Do not climb on roofs, railings, or posts, or on top of crawl through tube

✓ Slide sitting down, feet first, and on at a time. Do not slide up chutes or

✓ Adults – do not slide with a child or

your lap. It can injure your child's legs. ✓ Before letting go of overhead bars, hang down still, bend your knees a little

and drop straight down with both feet. $\checkmark\,$ Swing sitting down and do not jump

out while swinging. Do not twist chain


slides.


tubes.

HAGS[®] [©] Playpower inc hags@hags.com www.hags.com

Rocking Equipment MASW36720

Rev: 14 26/07/24





4609 [15'-1 1/2"]





out while swinging. Do not twist chain



Rev: 14 26/07/24

INSTALL

()