



S6




EN1176




2.99m

# EN1176





# ASTM F1487



 <b>INSTALL 101</b>	<p><b>WARNING</b> Playground equipment should not be used as a structure, scaffold or other surface for climbing, jumping or other activities. They are not designed for such use. Do not use for purposes other than intended. It is unsafe to climb on playground equipment.</p>	<p><b>play smart! rules</b></p> <ul style="list-style-type: none"> <li>✓ Do not play on broken or damaged equipment. Report it.</li> <li>✓ Do not play without adequate safety clothing and footwear.</li> <li>✓ No talking, running or shouting should be done while playing.</li> <li>✓ Do not play on top of equipment.</li> <li>✓ Do not play on or run on playground equipment and do not use it as a slide.</li> <li>✓ Wash your hands. Do not run, climb, swing, slide, or play roughhousing.</li> <li>✓ Do not play on swings or any equipment that is not designed for such use.</li> <li>✓ Do not slide on metal, concrete, or asphalt.</li> <li>✓ Do not climb on rails, ladders, or posts.</li> <li>✓ Do not slide up stairs or through holes.</li> <li>✓ Do not swing down, feet first, and one at a time. Do not slide up stairs or ladders.</li> <li>✓ Adults - do not slide with a child on your lap. It can injure your child's legs.</li> <li>✓ Before letting go of overhead bars, hand down with both feet and slide straight down with both feet.</li> <li>✓ Swing down with both feet and do not swing while swinging. Do not swing while swinging. Do not swing while swinging.</li> </ul>
	<p><b>WARNING</b> Children are required to use proper technique when using slides and other playground equipment. Before allowing children to play, verify that slides, ramps, and other equipment are properly installed and maintained.</p>	
	<p><b>WARNING</b> All playground equipment and rubber surfacing must be inspected for proper installation. Check for hot surfaces before allowing children to play. Children should wear appropriate shoes at all times.</p>	
	<p><b>WARNING</b> Playing high involves an inherent risk of injury. Playground equipment can be used to launch items from high, causing and head injury. Do not use equipment for other purposes. The manufacturer assumes no liability for injuries while playing and be careful.</p>	

**INSTALL 101**  

## HAGS®

FOR KIDS AGES


# 5-12

YEARS

ADULT SUPERVISION RECOMMENDED  
www.hags.com

S9




CSA Z 614

2.99m




[9'-10"]


# CSA Z614




 <b>INSTALL 101</b>	<p><b>WARNING</b></p> <p>Playground equipment used for test activities must be certified as suitable for the intended use and placed on a suitable surface. Check for holes and loose parts before allowing children to play.</p>	<p><b>play smart! rules</b></p> <ul style="list-style-type: none"> <li>Do not play on broken or damaged equipment.</li> <li>Do not play without adequate safety training and/or adult supervision.</li> <li>Do not play on or near any equipment if the labels, notices or drawings should be worn, or if any equipment is damaged.</li> <li>Do not play on or near any equipment if you are injured, or if you have a cast, brace, or other medical condition.</li> <li>Do not play on or near any equipment if you are wearing loose clothing or jewelry.</li> <li>Do not play on or near any equipment if you are under the influence of alcohol or drugs.</li> <li>Do not play on or near any equipment if you are using any equipment that is not certified for the intended use.</li> </ul>
	<p><b>WARNING</b></p> <p>Children are required to wear their safety harnesses and other playground equipment. Before allowing children to play, verify that the safety harness, helmet, seat, and other equipment are properly secured. Do not allow children to play if the equipment is damaged or if the child is not properly secured.</p>	
	<p><b>WARNING</b></p> <p>All playground equipment and other surfaces must be inspected for damage before allowing children to play. Children should wear appropriate shoes at all times.</p>	
	<p><b>WARNING</b></p> <p>Playground equipment can be used for other purposes. Check for holes and loose parts before allowing children to play. Children should wear appropriate shoes at all times.</p>	

 <b>INSTALL 101</b>
<h2>HAGS®</h2>
<p>FOR KIDS AGES</p> <h1>5-12</h1> <p>YEARS</p>
<p>ADULT SUPERVISION RECOMMENDED</p> <p><a href="http://www.hags.com">www.hags.com</a></p>









**Install 101**  
**260329**  
**420930**  
**420941**  
**420970**  
**441000**  
**450080**  
**450942**  
**450960**  
**42060530**  
**45071603**  
**45091210**  
**45275323**  
**45475323**  
**696305H**  
**MA422U75510**  
**MA424U75510**  
**MA45060523**  
**MA62693**  
**MASW103874**  
**MASW34156**  
**MASW35330**  
**MASW39775**





**MASW46128**  
**MASW53817**  
**MASW63820**  
**MASW63840**  
**MASW64540**  
**MASW85869**  
**ST4203**




**Above Ground**  
**OM**





**Cast Loose Fill**  
**BM**  
**8102043**










● **45475323** [BM]

● **45275323** [OM]


● **45071603**

● **MA424U75510** [BM]


● **MA422U75510** [OM]



● **MASW46128**



● **420941**



● **MASW35330**

● **696305H**

● **420930**

● **450960**


● **420970**


● **45091210**

● **45091210**

● **MASW35330**

● **450942**






MA62693

MA62693

MA62693

MASW39775

x10



MASW103874 [BM]

MASW85869 [OM]

