

# **Hand Sanitiser**

Inspection, Maintenance and Top up guide



## **Clearing Blockages:**

- Remove top lid by unscrewing the 4 bolts with a 4mm allen key T30 Torx Bit
- Remove side panel by removing all bolts on two sides with a 4mm allen key
- Remove the spray nozzle and fixings from the top of the hand surround box
- Remove the pipe feeding the nozzle from the foot pedal ①
- Unscrew the nozzle from the brass fitting ②
- With a airline blow the pipe and nozzle clear of any blockage
- Reconnect the pipe and nozzle and test before replacing in place
- When working replace all components and casings







#### **Refilling Installation:**

- Remove the top cap which is bolted using four Security Torx/Allen Bolts of M6
- Locate hose in the top of the unit
- Remove the tank filling cap
- Refill the tank with the Sanitiser liquid or gel
- Replace the tank filling cap
- Assemble the Top Cap with Security Torx / Allen Bolts.





### **General inspection and maintenance:**

- Remove leaves and debris from foot pedal area
- Remove graffiti
- Remove any rust using a rust converter
- Check that the mechanisms are working
- Paint over any chips
- Check for any breakages or sharp edges and report if any hazards are found to the site owner
- Clean the drip tray ideally with a generic 'anti-bacterial sanitiser'.
- Clean down outer unit with a generic 'anti-bacterial sanitiser'.
- Clean away any debris



# HAGS® Inspiring all generations

PlayPower